















STEP UP
הצעד הראשון לעיצוב הבית

TV4240TREV





Parts List

①  x1	②  x1	③  x1	④  x1
⑤  x1	⑥  x2	⑦  x2	⑧  x2
⑨  x2	⑩  x2		


Hardware List

A




M6x35 x10

B




Ø15x10 x10

C




Ø6x30 x20

D



Ø4x40 x10

E



Ø4x14 x8

F



x8

G




Ø4x14 x2

H



x2

I




x16

J




Ø3.5x14 x48

K





x4

L





x4


Step 1





Step 2





Step 3






Step 4




Step 5




Step 6




x2





x2





Step 7



Step 8

