









STEP UP
הצעד הראשון לעיצוב הבית







BY-DT3259-C





Parts List

①  x1	②  x1	③  x1
④  x2	⑤  x2	⑥  x12



Hardware List

A  x8	B  x8	C  Ø6x30mm x36	D  x1
E  4mm x1	F  M6x32mm x6	G  7x50mm x32	H  x6
I  x6	J  x6		


Step 1




Step 2






Step 3





Step 4




Step 5





Step 6



Step 7




H		x6
G		x16
E		x1

7x50mm

4mm



Step 8





C		x2
---	---	----

Ø6x30mm





Step 9



Step 10



Step 11



Step 12

